


Resetting Casio Calculators

Overview: All students must have access to calculators that meet the minimum requirements during the administration of North Carolina tests, when applicable. Prior to beginning and immediately following a test administration that requires calculator use, only the test administrator or principal's designee is required to clear the calculator memory and applications of all calculators to be used during the administration of the test.

Resetting the Calculator


- 1) Highlight the MEM Icon on the main menu and press EXE




- 2) Using the down arrow of the replay key move the highlighting to reset



- 3) Press F1 (Yes) to reset the calculator or F6 (No) to abort the operation.



- 4) Once window resets, it says Memory Cleared! Press Menu Key to return to the Main Menu



Quick Reset

You can reset the calculator by using an object like the thin pointed end of a paper clip. Simply locate the Small P-Button on the back of the calculator and press the button with the end of the paper clip. This will put the screen in Step 3. Reset All Memories mode then press F1 (Yes) to Reset or F6 (No) to abort the operation. Once reset, Press Menu to return to the Main Menu Screen.